



GrimmSpeed MAF Block Off Plate

Installation Instructions

2002+ Subaru WRX/STi

GrimmSpeed MAF Block Off Plate Installation Instructions

All GrimmSpeed components are intended for Off-Road use only.

Removing OEM MAF Sensor

1. Unplug MAF Sensor plug.
2. Remove (2) Philips head bolts.
3. Pull off OEM MAF Sensor.

Installing GrimmSpeed MAF Block Off Plate

1. Insert Block Off Plate Into MAF Sensor housing(make sure O-Ring does not slip off Block Off Plate).
2. Tighten down Plate with (2) Philips head bolts.

NOTE: Subarus are MAF based so you must relocate the OEM MAF Sensor after blocking the OEM Sensor location.

Please contact us if you have any questions during installation.
651.414.9747 or sales@grimmspeed.com.

Thank you for your purchase!